


**Program wireless wall remote control to your projection screen.**


*Program your iVisions wireless wall remote control.*




*The indication light will light up when you press a button. If the light doesn't light up, most likely the battery will be empty.*

#### **Program remote control - step by step –**

Remove the power plug from either the wall outlet, or the projection screen.



1. Press **[UP]** and hold this button.
2. Keep pressing the button **[UP]** for 5 seconds and reconnect the power while holding the button **[UP]**. Now the projection screen will start beeping.
3. Release the button and press the same button **[UP]** once (shortly).



4. The screen will now confirm the programming with a short 'beep-beep' sound.